


**RIVETEC** 

TITGEMEYER Group

Riveting Tool

**RL 75**

Operating Manual



# Table of contents

<b>Guiding instructions.....</b>	<b>4</b>
Cautions, instructions and procedural sections in the operating instructions .....	5
Markings on the riveting tool .....	6
<b>Safety instructions .....</b>	<b>7</b>
Basic requirements while dealing with the riveting tool .....	8
Noise and vibration levels of the RL 75.....	10
<b>Description of the riveting tool .....</b>	<b>10</b>
<b>Necessary tools .....</b>	<b>12</b>
<b>Storing the riveting tool/ tension heads.....</b>	<b>13</b>
<b>Preparing the riveting tool.....</b>	<b>14</b>
Select tension head .....	16
Assemble tension head .....	17

<b>Operating the riveting tool.....</b>	<b>21</b>
Set locking ring bolt .....	21
Setting the blind rivet.....	22
<b>Maintaining the riveting tool.....</b>	<b>23</b>
Bleeding the hydraulic section.....	23
Refilling hydraulic oil.....	24
Table for torque values .....	26
<b>Riveting tools/ Tension heads service and cleaning.....</b>	<b>27</b>
<b>Maintenance intervals .....</b>	<b>28</b>
<b>Trouble shooting.....</b>	<b>29</b>
<b>Disposal of the riveting tool .....</b>	<b>31</b>
<b>Technical data .....</b>	<b>31</b>
<b>Guarantee .....</b>	<b>32</b>
<b>List of parts .....</b>	<b>33</b>
<b>Declaration of conformity .....</b>	<b>35</b>

## Guiding instructions

<b>Instruction</b>	The legislator prescribes that the user must be well trained for using compressor-driven riveting tools. If desired, the training programme can be conducted at RIVETEC in Albrechtice n./Vlt. or directly at the client's place.
<b>Technological level</b>	This riveting tool is as per the latest technological standards. For the device to function properly, it is necessary to operate it in an expertly manner, with adherence to safety requirements.
<b>Reading the guiding instructions</b>	Before using the riveting tool for the first time, read the guiding instructions carefully.
<b>Procedures</b>	All the procedures necessary for the operation have been described in these guiding instructions. You may carry out only those procedures, which have been described here.
<b>Obstructions</b>	In case of obstructions, you may repair only those obstructions, which have been marked with an <b>O</b> (Operator).
<b>Illustrations and position-codes</b>	All the illustrations and position-codes in the individual diagrams take reference from the list of parts in the last pages.
<b>Table for torque values</b>	For sizes of screws and threads, you will find a table containing the torque values in the chapter "Maintaining the riveting tool".

## Cautions, instructions and procedural sections in the operating manual

Please follow the instructions and safety informations.

In this operating manual, some sections have been further illustrated through diagrams.

Please acquaint yourself well with these diagrams and their meanings:



**Caution** Hazard of injury! This marking indicates a potential hazard.



**Attention** Material damage! This marking points at a procedure, which may cause damage to the riveting tool or the work-piece.



**Note** This marking indicates useful information

- This point (•) marks every paragraph, which requires you to act by yourself.




**Attention** Environmental hazard! This marking indicates a potential environmental hazard.

### Markings on the riveting tool



This pictogram indicates that you must read the operating manual before using the riveting tool.



- A** Marking of the type
- B** Serial number
- C** CE-marking
- D** Instruction for reading the operating manual
- E** TÜV-Mark (safety checked)
- F** Name of the manufacturer and the value of the maximum operating pressure
- G** Supplier

## Safety instructions

### Application as per the purpose

The riveting tool is solely designed for setting locking ring bolts and blind rivets. The riveting tool RL 75 is designed for the processing of locking ring bolts with a nominal shaft diameter of 5.0 to 6.5 mm made of aluminium, steel and stainless steel and for blind rivets with a rivet shaft diameter of 5.0 to 6.5 mm made of aluminium, steel and stainless steel. This riveting tool must be used only as a hand-held device! The client is fully responsible for any modifications to the riveting tool!

### Improper use

Never throw away or drop the riveting tool!

### Clean and dry compressed air

Please take care that only clean and dry compressed air is let into the riveting tool. Moisture and dirt can damage the riveting tool. Use only such compressed air, which falls into class 2 of air quality as per ISO 8573-1.



**Caution** Hazard of injury because of explosion! Never use the riveting tool in an atmosphere prone to explosions. Ensure that the workplace is well lit and clean. Hazard of injury due to the openly moving compressed air hose. Connect and lay the compressed air hose properly. Hazard of injury due to tripping over! Lay the compressed air hose in such a way that nobody should trip over it.



**Attention** Material damage! The maximum operating pressure is 7 bar. For increasing the durability of the riveting tool, it is recommended to fit a compressed air-maintenance unit in the compressed air hose.

### Basic requirements while dealing with the riveting tool



**Caution** Do not operate the riveting tool when it is directly pointing at any person.  
Follow the prevalent guidelines for the prevention of accidents in the respective country.  
Use only those fittings and hoses, which have been approved for the operating pressure.  
Disconnect the compressed air supply from the riveting tool at the time of installation or maintenance.  
Wear personal safety gear (safety glasses and safety helmet).



**Attention** Pay attention to the details on the packaging of the blind rivets or locking ring bolts.  
Use the riveting tool only at operating temperatures above 5°C and 45°C.  
Always use the fitting tension head for every type of blind rivet, locking ring respectively.  
Do not throw away the riveting tool.

### Maintenance and servicing

The operator may only carry out the maintenance and repair work described in these operating instructions.

### Service instructions

Maintenance and service work not described in these operating instructions may only be carried out by trained specialists following instruction by RIVETEC on the basis of the service instructions which also exist. See the address on page 34 for more information on service instructions and training.





**Note** The manufacturer accepts no liability for damage resulting from incorrect repairs or the use of spare parts from other sources.

At the time of leaving the workplace, do not leave the riveting tool with pressure on.

**Guarantee** A guarantee is void, if any repair work carried out on the riveting tool has lead to any damage of the riveting tool.

**Declaration of conformity** The riveting tool RL 75 has been checked and manufactured according to European guidelines. The declaration of conformity can be found on the second last page.

**GS-checked** In addition to this, the riveting tool has been checked by the TÜV Product Service GmbH, Hannover, and certified with a GS-mark.

### Noise and vibration levels of the RL 75


**Noise level** The sound-emission level for workplaces is  $L_{PAI} < 70 \text{ dB(A)}$  as per ISO 10843 and DIN EN 3744.

**Vibration level** The effective value measured on acceleration with the handle, as per ISO/FDIS 8662-11, is  $a_{hw} < 2,5 \text{ m/s}^2$ .


## Description of the riveting tool

The riveting tool RL 75 works according to a pneumatic-hydraulic principle.

It consists of the following operation-related components:



- |   |                   |  |
|---|-------------------|--|
| 1 | Knurled nut       | fixes the tension head   |
| 2 | Nose cap          | covers jaw case body   |
| 3 | Hydraulic housing | the pneumatic and the hydraulic units are located in the hydraulic housing |
| 4 | Hang-up eyelet    | for hanging up on a hook whenever stationary                               |
| 6 | Collector         | collects the torn off mandrel, tension part respectively                   |




**Note** The socket head screw (7) and the O-ring (8) are screwed tightly into the grip. The socket head screw (7) must not be loosened, else the hydraulic oil will leak.

- |           |                   |  |
|-----------|-------------------|--|
| <b>7</b>  | Socket head screw | locking for the hydraulic oil system   |
| <b>8</b>  | O-Ring            | sealing of the hydraulic oil system  |
| <b>9</b>  | Safety valve      | (Brass) In case of very high pressures (approx. 8 bar or more), it opens, and lets the air out |
| <b>10</b> | Plug              | serves the purpose of protection of the thread and also against dirt                           |
| <b>11</b> | Swivel-joint      | serves as the connection for compressed air hoses (operating pressure 6 bar)                   |
| <b>13</b> | Trigger           | when activated, the riveting procedure starts  |

## Necessary tools

You will require the following tools for all installation, servicing and maintenance work.



### Tools

- Crank (16)
- Internal hex key (17)
- Wrench<sup>1</sup>
  
- Slotted screw driver<sup>1</sup>

SW4  
SW13, SW14, SW15,  
SW17, SW18, SW20

<sup>1</sup> No delivery possibility

## Storing the riveting tool/ tension heads

### Until first use

If you do not intend to use the riveting tool immediately, store the riveting tool and the tension heads in their original packaging - in a dry and dust-free condition.


### Long-term storage after usage


Turn collectors (6) off, screw out swivel joint (11) and close the opening with the plug (10). Dismantle tension head and lubricate with acid-free grease. If possible, store all pieces in the original packing.

### After long-term storage

After long-term storage (about 3 years), change the hydraulic oil before re-use.

A hydraulic oil change may only be carried out by trained specialist with the help of the service instructions. For further information regarding service instructions and training, please see the address on page 34.





**Package insert**

## Preparing the riveting tool

The components ordered by you are marked as per the checklist found inside the packing.




**Note** Please check the contents of the packing, for completeness of the checklist

In every case, please carry out a visual check of the riveting tool before starting any work:

- for external damages,
- for oil leakage from the riveting tool.

- Remove the plug (10) from the connection port, and store in the original packing.





**Note** The swivel joint (11) and the safety valve (9) can be alternatively fitted on both the sides of the hydraulic housing. The diagram below shows the arrangement for a right-hander.



**Note** In case of all screw-fittings, observe the table for torque values in the chapter "Maintaining the riveting tool"

- Screw on the swivel joint (11) and tighten using the wrench SW17 (see page 26 "Table for torque values").





**Note** Depending on the type of compressed air supply, it may be necessary to connect a fitting different from the one provided, to the riveting tool. For this, you need to have a fitting having a 1/4" Withworth pipe thread as per ISO 228.



**Attention** Material damage by compressed air!  
As per norm ISO 8573-1, class 2, compressed air must be dry and clean. We recommend that you fit a compressed air-maintenance unit to the riveting tool.

- Compressed air hose should be connected to the swivel joint (11), as prescribed.



**Note** The operating pressure must be between a minimum of 5 and a maximum of 7 bar!

## Preparing the riveting tool

### Select tension head

You can modify the riveting tool to process locking ring bolts and blind rivets of varying sizes and materials by changing the tension head. If a different tension head has already been mounted, dismantle it in compliance with the assembly description in reversed sequence.

Always check the tension head before every assembly for outer damages. The tension heads have to be ordered separately.

You can see which tension head is to be used from the following table.

	Type	Ø*	Material	Tension head	Assembly
<b>Lock. ring bolt</b>	C106/ C6L	5.0	Alu./ steel/ stainless steel	99-2555	Page 17
		6.0/ 6.5	Alu./ steel/ stainless steel	99-2561	
	MAGNA-GRIP	5.0 6.5	Alu./ steel Alu	99-1456 99-1458	Page 17
	Tainer	6.5	Steel	99-3465	Page 20
<b>Blind rivet</b>	MAGNA-LOK and MAGNA-BULB	5.0	Alu./ steel/ stainless steel	99-3303	Page 18
		6.5	Alu./ steel/ stainless steel	99-3305/ 06	
	BOM	5.0	Steel	99-994	Page 19


\* Blind rivet: Rivet shaft diameter; locking ring bolt: Nominal shaft diameter

The tension head 99-3465 (Tainer) can only be mounted to the MS 75 by means of a special nose cap that has to be ordered separately (see “list of parts” on page 33).




### Mount tension head (99-1456; 99-1458; 99-2555; 99-2561)

Before mounting the tension head, make sure that you have chosen the right tension head (see table on page 16).



The assembly is identical for the tension heads listed.  
The tension head 99-2561 is displayed in the illustrations.

- Loosen compressed air connection.
- Screw (2) nose cap off.
- Insert O-Ring (C) with slotted screw driver in the groove on the jaw case body (12) (O-Ring (C) is included with the tension head).
- Grease O-Ring (C) and thread on the jaw case body (12) lightly with acid-free grease (Vaseline).
- Screw jaw case (B) onto the jaw case body (12) and tighten at a torque of 12 Nm.
- Slip nose cap (2) without knurled nut (1) over the jaw case (B), screw into the hydraulic housing (3) and tighten at a torque of 20 Nm.
- Slip tension head case (A) over the jaw case (B) and push into the nose cap (2) up to the limit.
- Slip knurled nut (1) over the tension head case (A), screw onto the nose cap (2) and screw hand tight.





## Preparing the riveting tool

### Mount tension head (99-3303; 99-3305; 99-3306)

Before mounting the tension head, make sure that you have chosen the right tension head (see table on page 16).

The assembly is identical for the tension heads listed.


The tension head 99-3303 is displayed in the illustrations.



- Loosen compressed air connection.
- Screw (2) nose cap off.
- Insert O-Ring (C) with slotted screw driver in the groove on the jaw case body (12) (O-Ring (C) is included with the tension head).
- Grease O-Ring (C) and thread on the jaw case body (12) lightly with acid-free grease (Vaseline).
- Screw nose piece (M) tension head case (A) and tighten at a torque value of 5 Nm.
- Screw jaw case (B) onto the jaw case body (12) and tighten at a torque of 12 Nm.
- Slip nose cap (2) without knurled nut (1) over the jaw case (B), screw into the hydraulic housing (3) and tighten at a torque of 20 Nm.
- Slip tension head case (A) over the jaw case (B) and push into the nose cap (2) up to the limit.
- Slip knurled nut (1) over the tension head case (A), screw onto the nose cap (2) and screw hand tight.

## Mount tension head (99-994)

Before mounting the tension head, make sure that you have chosen the right tension head (see table on page 16).




- Loosen compressed air connection.
- Screw (2) nose cap off.
- Insert O-Ring (C) with slotted screw driver in the groove on the jaw case body (12) (O-Ring (C) is included with the tension head).
- Grease O-Ring (C) and thread on the jaw case body (12) lightly with acid-free grease (Vaseline).
- Hold guide case (H) upright, slip on pressure spring (G) and jaw bearing (F).
- Place jaws (E) on the jaw bearing (F).
- Carefully slip jaw case (B) over guide case (H) up to the limit stop.
- Slip safety case (D) and jaw case (B) into each other.
- Slip jaw case (B) into the jaw case body (12) up to the limit.
- Screw jaw case (B) onto the jaw case body (12) and tighten at a torque of 12 Nm.
- Slip nose cap (2) without knurled nut (1) over the jaw case (B), screw into the hydraulic housing (3) and tighten at a torque of 20 Nm.
- Slip tension head case (A) over the jaw case (B) and slip under the nose cap (2) up to the limit.
- Insert washer (U) into the knurled nut (1).
- Slip knurled nut (1) over the tension head case (A), screw onto the nose cap (2) and screw hand tight.

## Preparing the riveting tool

### Mount tension head (Tainer 99-3465)


Before mounting the tension head, make sure that you have chosen the right tension head (see table on page 16).



#### Note

You need a special nose cap (2a) for the assembly of the tension head and which you have to order separately (see page 33 “list of parts”):

- Loosen compressed air connection.
- Screw (2) nose cap off.
- Insert O-Ring (C) with slotted screw driver in the groove on the jaw case body (12) (O-Ring (C) is included with the tension head).
- Grease O-Ring (C) and thread on the jaw case body (12) lightly with acid-free grease (Vaseline).
- Screw jaw case (B) onto the jaw case body (12) and tighten at a torque of 12 Nm.
- Slip nose cap (2a) over the jaw case (B), screw into the hydraulic housing (3) and tighten at a torque of Nm 20.
- Slip tension head case (A) over the jaw case (B).
- Screw tension head case onto the nose cap (2a) and tighten at a torque of 8 Nm.



## Operating the riveting tool

### Set locking ring bolt




**Note** The tension head and locking ring bolts you implement may look a little different than shown in the following illustrations



**Attention** Material damage! Always set the riveting tool at the correct angle (90°) with the surface of the work-piece to be riveted. A slanted setting will lead to defective riveting.






**Note** For the size of the hole (d1) and of the clamping grip (K), refer to the information given by the rivet manufacturer. The illustration on the left shows the position of the locking rings for locking ring bolts C106/ C6L (a1)/(b1) and MAGNA-GRIP (a2)/(b2).



- Connect compressed air (6 bar).
- Place the locking ring bolt (a) into the prepared bore.
- Slip locking ring (b) in the correct position over the tension part of the locking ring bolt (a).
- Hold up the locking ring bolt (a) at the head. Slip the riveting tool with the tension head (Z) over the tension part of the locking ring bolt (a) and against the locking ring (b) and press tightly.
- Press trigger (13) through up to the limit and hold. The tension head drives over the locking ring bolt in the process it is shaped in such a manner that the material always presses into the grooves of the shaft.
- Release trigger (13). The torn off tension part is transported to the collector (6) in the next riveting cycle.

## Operating the riveting tool



### Setting the blind rivet



**Note** The tension head and blind rivet you implement may look a little different than shown in the following illustrations




**Attention** Material damage! Always set the riveting tool at the correct angle (90°) with the surface of the work-piece to be riveted. A slanted setting will lead to defective riveting.



**Note** For the size of the hole (d1) and of the clamping grip (K), refer to the information given by the rivet manufacturer

- Connect compressed air (6 bar).
- Insert blind rivet (a) in tension head (Z).
- Insert blind rivet (a) into the prepared bore and press tightly.
- Straighten the trigger (13) upto the stop point, and hold it there. The rivet shaft is clenched and the blind rivet set by.
- Releasing trigger (13). The torn off mandrel is transported latest after the next riveting process into the collector (6).



## Maintaining the riveting tool

**Caution** Hazard of injury if handled in an improper manner! Servicing, maintenance and repairs of the riveting tools must be carried out professionally. On completing this work, there should not be any more hazard to the operator, if used as per the regulations. The operator may only carry out the operations mentioned here.

### Bleeding the hydraulic section

It is necessary to bleed the hydraulic system or to refill the hydraulic oil when:

- oil is leaking from defective O-rings,
- after an oil-change at the time of an overhaul (either after a maximum of 3 years, or after 2000 working hours).


- Detach the compressed air connection.



**Note** If you clamp the riveting tool into a vice, then insert a soft material in-between (Alu/ wood). Screw off tension head case to avoid pressure on the hydraulic rod as otherwise you cannot fill in enough oil (also see pages 17 - 20 “Mount Tension head”)

- Bend the riveting tool carefully towards the front at an angle and fix e.g. inside a vice (like illustrated in the diagram). This position makes it possible for enclosed air to escape.
- Unscrew the socket head screw (7) in the hydraulic housing carefully using the internal hex key SW4.

## Maintaining the riveting tool



### Refilling hydraulic oil

**Attention** Environmental hazard! Always use a large bowl for collecting oil. Please observe all the environmental regulations prevalent in the respective area.

**Attention** Material damage! Do not let the O-ring (8) be damaged. If the O-ring gets damaged, then replace immediately.


- Unscrew the socket head screw (7) in the hydraulic housing carefully, using the internal hex key SW4.
- Screw the oil refill adapter screw (15) into the free opening.
- Set the filled oil gun (14).
- Screw socket head screw (7) out of the device floor with the internal hex key SW4.
- Insert the crank (16) into the free opening and screw up to the limit.
- Pull crank (16) out until the marking is flush with with the floor plate.



**Note** By this piston movement hydraulic oil (e.g. DEA Astron HLP 32 or equivalent) is drained into the hydraulic area from the plugged in oil gun


- Press oil gun (14) remove and screw out oil refill adapter screw (15).





- Screw socket head screw (7) with O-Ring (8) into hydraulic housing and tighten with internal hex key SW4 (see page 26 “Table for torque values”).
- Screw crank (16) out.
- Screw socket head screw (7) with O-Ring (8) into the device floor and tighten with internal hex key SW4 (see page 26 “Table for torque values”).
- Rub the riveting tool dry.
- Loosen the fixed riveting tool.
- Mount tension head (see pages 17 - 20 “Mount Tension head”).
- Reconnect the compressed air supply.
- Carry out a work cycle without blind rivet/ locking ring bolt.

## Maintaining the riveting tool



### Table for torque values

In the following table, you will find torque values, which you are required to adhere to while tightening the screws/ nuts.

Pos.	Name	Threading	Torque value MA in Nm
2	Nose cap	Metrical M26x1,5	20
2a	Nose cap (Tainer)	Special thread	8
12.1	Jaw case body	Metrical M13	12
12.2	Jaw case body	Metrical M11x1	12
5	Lock nut	Metrical M11x1	12
7	Socket head screw	Metrical M6	4
9	Safety valve	Withworth-pipe- thread 1/4"	20
11	Swivel joint	Withworth-pipe- thread 1/4"	20

## Riveting tools/ Tension heads service and cleaning



**Caution** Hazard of injury if handled in an improper manner! On completing this work, there should not be any more hazard to the operator, if used as per the regulations. The operator may only carry out the operations mentioned here. Maintenance and service work not described in this operating manual may only be carried out by trained specialists following instruction by RIVETEC on the basis of the service instructions which also exist. See the address on page 34 for more information on service instructions and training.

Hazard of injury if the riveting tool falls down! The hydraulic housing must always be kept dry, clean and oil- and fat-free.



**Attention** Material damage due to corrosion! Do not use any highly active cleaning agents or combustible liquids for cleaning purpose!

The following routine is recommended:

Clean riveting tool and tension heads after completion of cycle with this type and check for mechanical defects.

After the riveting tool and the tension head have been cleaned and if they are to be stored over a longer period of time, apply a little acid-free oil (e.g. ELFOLNA 46) to all metal, outer components.

## Maintenance Intervals

Intervall	Activity	How?	Who?	Remark
Daily before use	Check for cracks	Visual check	Operator	If cracks or tears occur send the device to maintenance
Daily before use	Check tension head for wear	Visual check	Operator	If necessary replace tension head
Daily before use	Check the jaws in the tension heads	Functional check	Operator	If required, clean and change jaws (see pages 17 -20 "Mount Tension head")
Daily before use	Check for oil leaks from the riveting tool	Visual check, possibly fill up with recommended oil, bleed hydraulic system	Operator	see page 23 ("Maintaining the riveting tool")
Daily after use	Clean riveting tool  Oil moving parts	With a rag  With acid-free oil e.g. ELFOLNA 46	Operator	—
Either throughout the 3 years or after a period of 2000 working hours	Change hydraulic oil	With acid-free oil e.g. DEA Astron HLP 32	Professional	A complete oil change, to be carried out only by a professional

## Trouble shooting

Operations, which may be carried out by the operator, are marked with the letter **O**.

Operations, which may be carried out only by an expert person, are marked with the letter **P**.



**Caution** Hazard of accident! In any case, keep the compressed air supply detached till the source of the problem is eliminated.



**Attention** Material damage! Operations, which have been marked with the letter **P**, must be carried out only by well- trained experts. Deliver riveting tool from overhaul


Any replacement of original spare parts may be carried out only by well-trained experts.



**Note** After every instance of problem- removal, a thorough functional check must be carried out (check whether a stroke is being carried out)

## Trouble shooting

Problems	Cause	Solution
Blind rivet/ locking ring bolt is not riveted	Supply of compressed air is too rare  Jaws are dirty Jaws are worn out  Jaw case body loose  Oil lacking/ too little stroke	(O) Check compressed air supply (O) Set the compressed air setting on the maintenance unit at a maximum of 7 bar (O) Clean tension head (O) Replace jaws, tension head respectively (see page 17 - 20 "Mount tension head") (O) Tighten the screws/ nuts (see page 17 - 20 "Mount tension head") (O) Check oil volume and refill (see page 23 "Maintaining the riveting tool")
Blind rivet/ locking ring bolt cannot be inserted	Wrong tension head  Tension head loose  Travel-path of the mandrel is blocked	(O) Replace tension head (see page 17 - 20 "Mount tension head") (O) Tighten the screws/ nuts (see page 17 - 20 "Mount tension head") (O) Empty collector
Stroke is too short	Oil level is too low  Not bled correctly	(O) Check oil volume and refill (see page 23 "Maintaining the riveting tool") (O) Bleed the hydraulic system (see page 23 "Maintaining the riveting tool")
Loss of hydraulic oil due to leakage	Leaking and worn out O-rings inside the riveting tool	(P) Deliver riveting tool from overhaul
Safety valve gets blown off	Compressed air pressure is too high Valve is defective	(O) Check and adjust compressed air setting (O) Replace safety valve



## Disposing of the riveting tool

Ensure that the hydraulic oil is inside the riveting tool. Dispose it off in an environmentally friendly manner. Send the riveting tool back to the manufacturer in it's original packing, if still available.

## Technical data

Type of riveting tool:	RL 75
Height:	320 mm (without tension head)
Width:	275 mm (without tension head)
Weight:	1.9 kg
Operating pressure:	5-7 bar
Compressed air supply nominal diameter:DN 6	
Power output (at 6 bar):	approx. 24 kN
Operating stroke:	approx. 15 mm

### Operating range

Locking ring bolt:	
C106/ C6L	5.0 - 6.5 mm
MAGNA-GRIP	5.0 and 6.5 mm
Blind rivet:	
MAGNA-LOK/ BULB	5.0 and 6.5 mm
BOM	5.0 mm

Sound emission level in the workplace:	$L_{PAI} < 70 \text{ dB(A)}$
Vibration level:	$a_{hw} < 2,5 \text{ m/s}^2$

Further technical data on the tension heads are enclosed with the tension heads.

## **Guarantee**


Other than the official guarantee (6 months), the company RIVETEC also offers a guarantee of an additional 6 months from the date of purchase (The bill being the proof thereof).

The following working parts are excluded from the guarantee agreement:

- Collector (6)
- Socket head screw (7) with O-ring (8)
- Tension heads




# 20-0301: [variant]




## Příslušenství k připojení, údržbě, uskladnění

Accessories for connecting, upkeep, stowage



## 20-0342



## Přehled Overview

Objednáací číslo Part No.	Název	Description	Ks Pcs	V
10-0104	Zajišťovací matice	Lock Nut	1	
10-0191	Hubice	Nose Cap	1	
10-0192	Mezikus	Jaw Case Body	1	
10-0194	Matice	Nut	1	
10-0250	Táhlo	Crank	1	
10-1202	Reduktor	Reducer	1	
20-0008	Pojistný ventil komplet	Safety Valve, cpl.	1	
20-0072	Těsnící šroub komplet	Fill Screw cpl.	1	
20-0171	Plnicí šroub komplet	Oil Refill Adapter Screw	1	
20-0342	Vzduchový přípoj - komplet	Swivel-joint, cpl.	1	
30-0173	Pojistný kroužek pro hřídele	Retained Ring	1	
30-0178	O-kroužek 5x2	OR 5x2 90 Shore	1	
30-0228	O-kroužek 7.1x1.6	OR 7,1x1.6 70 Shore	2	
30-0288	Stříkačka na olej	Oil Syringe	1	
30-0293	Klíč imbusový č.4	Internal Hex Key SW 4	1	
30-0320	Lapač trnů	Deflector	1	V
30-0491	Těsnění 1/4" - bílé	Seal	1	

\*V – díly na které se nevztahuje záruka, spare-parts without guarantee

Název produktu:  
Product Name: **RL 75**

Kat. číslo:  
Cat. Number: **99-0026**

Určení produktu:  
Specifications: pneumaticko-hydraulické nýtovací nářadí pro usazování jednostranný nýtů  
air-hydraulic riveting tool for installing blind rivets

Výrobce

Manufacturer

RIVETEC s.r.o.  
Albrechtice nad Vltavou 16  
CZ-39816 Albrechtice nad Vltavou  
IČ 60647761

prohlašuje, že výše uvedený výrobek odpovídá  
následujícím evropským normám a směrnicím  
a byl navržen, vyroben a posouzen ve shodě  
s platnou legislativou ČR:

declares that the product listed is in conformity  
with the essential requirements and provisions  
of following Council Directives and conforms  
to the following standards:

ČSN EN ISO 12100 Bezpečnost strojních zařízení  
ČSN EN 349 Bezpečnost strojních zařízení – Nejmenší mezery k zamezení sličených částí lidského těla  
ČSN EN 953 Bezpečnost strojních zařízení – Ochranné kryty  
ČSN CR 954-100 Bezpečnost strojních zařízení: části řídicích systémů  
ČSN EN 983 Bezpečnost strojních zařízení – Bezpečnostní požadavky pro fluidní zařízení a jejich součásti – Pneumatika  
ČSN EN 999 Bezpečnost strojních zařízení – Umístění ochranných zařízení s ohledem na rychlosti přiblížení částí lidského těla  
ČSN EN 61000-6-1 ed. 2 Elektromagnetická kompatibilita – Odolnost  
ČSN EN 61000-6-4 ed. 2 Elektromagnetická kompatibilita – Emise  
ČSN EN 60204-1 Bezpečnost strojních zařízení – Elektrické zařízení strojů – Všeobecné požadavky  
ČSN EN ISO 13850 Bezpečnost strojních zařízení – Nouzové zastavení – Zásady pro konstrukci  
ČSN EN ISO 13857 Bezpečnost strojních zařízení – Bezpečné vzdálenosti k zamezení dosahu k nebezpečným místům horními a dolními končetinami  
ČSN EN ISO 1037 Bezpečnost strojních zařízení – Zamezení neočekávanému spuštění  
ČSN EN 614-1 Bezpečnost strojních zařízení – Ergonomické zásady navrhování – Část 1  
ČSN EN 60439-1 ed. 2 Rozvaděče nn – Část 1  
2006/95/ES Elektrická zařízení určená pro používání v určitých mezích napětí  
2004/108/ES Elektromagnetická kompatibilita  
2006/42/ES Směrnice o strojích a zařízeních

Zákon č. 22/1997 Sb. o technických požadavcích  
Zákon č. 71/2000 Sb. (změna zákona č. 22/1997 Sb.)  
Zákon č. 205/2002 Sb. (změna zákona č. 22/1997 Sb.)  
Zákon č. 226/2003 Sb. (změna zákona č. 22/1997 Sb.)  
Zákon č. 102/2001 Sb. o obecné bezpečnosti výrobků  
Zákon č. 227/2003 Sb. (změna zákona č. 102/2001 Sb.)  
Nařízení vlády č. 18/2003 Sb. o požadavcích na výrobky z hlediska jejich elektrické kompatibility  
Nařízení vlády č. 204/2003 Sb. o technických požadavcích na strojní zařízení

Místo a datum:  
Place and date: **Albrechtice nad Vltavou**  
**27.11.2008**

Jméno, funkce a podpis autorizované osoby:  
Name, Title and Signature of Authorized Person:

**Ing. Antonín Solfronk**  
Managing Director





*TITGEMEYER Group*

RIVETEC s.r.o.  
Albrechtice nad Vltavou 16  
CZ - 398 16

Tel.: +420 382 206 711  
Fax: +420 382 206 719

[info@rivetec.cz](mailto:info@rivetec.cz)  
[www.rivetec.eu](http://www.rivetec.eu)