



Article Nr. / Obj. č.:

**87-0159**

**Trigger Assembly**  
Tlačítko komplet

www.rivetec.cz

RIVETEC E131119



Part / Díl	Pcs / Ks
10-0064	1
10-0205	1
10-0209	1
10-0210	1
10-0217	1
10-0314	1
10-0693:zelená	1
10-0708	1
30-0004	1
30-0007	1
30-0083	1
30-0140	1
30-0189	1
30-0201	2