









RIVETEC <small>TITGEMEYER Group</small>	Instruction For Use	No.: 05071201/48	Page 1 z 2
Done by: A.Seiner	Inductive Sensor	Version: 1	Date: 2005-07-11

Inductive sensor




	Instruction For Use	No.: 05071201/48	Page 2 z 2
Done by: A.Seiner	Inductive Sensor	Version: 1	Date: 2005-07-11

WIRING DIAGRAMS



CONNECTION



Continuous voltage 10 ÷ 30VDC

Max output current 80 mA

RIVETEC s.r.o.

Albrechtice nad Vltavou 16

CZ 398 16

Telefon: +420 382 206 711

Telefax: +420 382 206 719

E-mail: info@rivetec.cz

www.rivetec.cz